



Assembly & Installation Instructions for: 028722-014-FR001 4-Light Wall lamp

Customer Service :(702)361-4345,(800)525-2655,customer.service@kalco.com



WARMING - TO REDUCE THE RISK OF FIRE OR INJURY:

- 1.If you are unfamiliar with electricalwiring, call a qualified electrician to install this unit .More than one person may be necessary to install fixture ,make sure you have enough qualified help.
- 2.Turn off the power to the fixture's circuit at the service panel. Use a coltage detector to verify that the power is off.
- 3.DO NOT install bulb which exxeeds the maximum wattge specified on the socket label.







Assembly & Installation Instructions for: 028722-014-FR001 4-Light Wall lamp


BY KALCO LIGHTING


Customer Service :(702)361-4345,(800)525-2655,customer.service@kalco.com

Fixture Assembly









В

12

ALLEGRI BY KALCO LIGHTING

Assembly & Installation Instructions for: 028722-014-FR001 4-Light Wall lamp

Customer Service :(702)361-4345,(800)525-2655,customer.service@kalco.com

Fixture Assembly

- Step 5. Fasten 2 (state specification of screw) into mounting plate so that they extend away from wall when mounting plate is installed
- Step 6. Attach the mounting plate to outlet box with sorews
- Step 7. Refer to wiring diagram. Splice the ribbed side of fixture cord to the white supply wire from outlet box with wire connector. Splice the smooth side of the fixture cord to black supply wire from outlet box with wire connector
- Step 8. Carefully tuck in all wires Attach the backplate with the mounting screw on the crossbar.Secure fixture with shell hnobs.

